



When spraying shotcrete or other materials against Paraseal LG, spray either directly at the seam or at the closed edge of the seam so as not to lodge sprayed materials between the lapped sheets. Never spray into open edge of seam.

Seams may run either horizontal or vertical. When running horizontal, the open edge of the 100mm seams shall be aiming up or shingled as shown.

Lap seams minimum 100mm and secure with wide crown box staples located at 75mm O.C.

In order to prevent penetrations and damage to the membrane use concrete dobies or plastic sand chairs between the rebar and the Paraseal LG to hold the Paraseal LG tight against the lagging.

NOTE: Paraseal products require a min of 117 kg/m² of compaction/confinement in order to function as designed.

NOTE: Not recommended for use in submerged conditions.

NOTE: Fasteners only to be located at the seams; all fasteners located outside of the seam area shall be driven through a piece of Tremco Water-Stop or covered with Parastick N Dry that is adhered with Paraprimer.



www.tremco.com.au
12/4 Southridge St, Eastern Creek, NSW 2766
Phone: (02) 9638 2755 Fax: (02) 9638 2955

Project: Paraseal Blindside Walls

Detail: Typical Seam Detail

Sheet Number:

File Name:
PBSW - Seam
Detail

Rev #:

01

This detail is intended for conceptual purposes only.

Drawn by: SP

Checked by: XX

Scale: N.T.S

Date: 10/11/2020